



**Advantech**  
**Wireless**

**OPERATION MANUAL**

**70 MHz TO L-BAND**

**INDOOR UP-CONVERTER**

**ARUN-70L**

**PM 170-705000-201, Rev. 2n**

## WARRANTY

This Advantech Wireless product is warranted against defects in material and workmanship for a period of 2 years from date of shipment. During the warranty period, Advantech Wireless will, at its option, either repair or replace the product, which proves to be defective.

To return a product for warranty or repair service, first request a Return Material Authorization (RMA) number by contacting Advantech Wireless at:

Phone: (514) 420-0045 or Fax: (514) 420-0073  
Website: [www.advantechwireless.com](http://www.advantechwireless.com) or e-mail: [support@advantechwireless.com](mailto:support@advantechwireless.com)

The product should be shipped to the following address, in the original shipping container (box), with the prepaid shipping charges.

Advantech Wireless  
657 Orly Avenue  
Dorval, Quebec  
H9P 1G1  
CANADA

Please indicate the RMA number on all shipping documentation.

Units shipped without a prior issued RMA, or not shipped in the original container, may be rejected and returned at sender's expense.

## LIMITATIONS OF WARRANTY

Advantech Wireless warrants this product to be free of defects in materials and workmanship.

The foregoing warranty shall not apply to defects resulting from improper handling or abuse by the purchaser, unauthorized modification, operating outside of the product's environmental specifications, improper installation or maintenance.

*Advantech Wireless shall not be liable for any direct, indirect, special, incidental or consequential damages.*

## CONTENTS

<b>1. INTRODUCTION</b> .....	<b>7</b>
<b>2. PRODUCT DESCRIPTION</b> .....	<b>8</b>
<b>3. MONITORING AND CONTROL BY THE FRONT PANEL</b> .....	<b>13</b>
3.1 KEYPAD AND FLUORESCENT DISPLAY .....	13
3.2 GAIN ADJUSTMENT.....	13
3.3 LEDs.....	17
<b>4. MONITORING AND CONTROL BY THE DISCRETE INTERFACE</b> ....	<b>18</b>
<b>5. MONITORING AND CONTROL BY THE RS-232 INTERFACE</b> .....	<b>19</b>
5.1 ELECTRICAL CONNECTION.....	19
5.2 PORT SETTINGS .....	19
5.3 COMMAND DESCRIPTION .....	20
<b>6. MONITORING AND CONTROL BY THE RS-485 INTERFACE</b> .....	<b>24</b>
6.1 ELECTRICAL CONNECTION.....	24
6.2 PORT SETTING.....	24
6.3 PROTOCOL OVERVIEW .....	25
6.4 COMMAND MESSAGES .....	27
6.4.1 <i>REQUEST STATUS (0x01 OR 0x2A)</i> .....	28
6.4.2 <i>SET MUTE/UN-MUTE (0x02)</i> .....	29
6.4.3 <i>SET FREQUENCY (0x04)</i> .....	30
6.4.4 <i>SET GAIN (0x05)</i> .....	31
6.4.5 <i>READ IDENTIFICATION (0x07)</i> .....	32
6.4.6 <i>READ SERIAL NUMBER (0x08)</i> .....	33
6.4.7 <i>READ FREQUENCY RANGE (0x09)</i> .....	34
6.4.8 <i>READ GAIN (0x0A)</i> .....	35
6.4.9 <i>READ GAIN RANGE (0x0D)</i> .....	36
6.4.10 <i>READ FREQUENCY (0x0F)</i> .....	37
6.4.11 <i>READ TEMPERATURE (0x12)</i> .....	38
6.5 RESPONSE MESSAGES .....	39
6.5.1 <i>STATUS MESSAGE</i> .....	39
6.5.2 <i>IDENTIFICATION MESSAGE</i> .....	41
6.5.3 <i>SERIAL NUMBER MESSAGE</i> .....	42
6.5.4 <i>FREQUENCY RANGE MESSAGE</i> .....	43
6.5.5 <i>GAIN MESSAGE</i> .....	44
6.5.6 <i>GAIN RANGE MESSAGE</i> .....	45
6.5.7 <i>FREQUENCY MESSAGE</i> .....	46
6.5.8 <i>TEMPERATURE MESSAGE</i> .....	47

---

<b>7. PRODUCT SPECIFICATIONS .....</b>	<b>48</b>
<b>8. PACKING LIST .....</b>	<b>49</b>
<b>9. APPENDIX A: SAFETY AND EMC COMPLIANCE .....</b>	<b>50</b>

## FIGURES

<b>FIGURE 1: OUTLINE DRAWING</b> .....	10
<b>FIGURE 2: FRONT AND BACK PANELS</b> .....	11
<b>FIGURE 3: BLOCK DIAGRAM</b> .....	12
<b>FIGURE 4: MONITOR AND CONTROL MENU</b> .....	14
<b>FIGURE 5: SHELF MENU</b> .....	15
<b>FIGURE 6: HELP MENU</b> .....	16
<b>FIGURE 7: RS232 HELP MENUS</b> .....	22
<b>FIGURE 8: RS232 STATUS COMMAND AND RESPONSE</b> .....	23

## TABLES

<b>TABLE 1: CONNECTORS</b> .....	9
<b>TABLE 2: LED INDICATORS</b> .....	17
<b>TABLE 3: DISCRETE INTERFACE – PIN ASSIGNMENT</b> .....	18
<b>TABLE 4: RS-232 INTERFACE – PIN ASSIGNMENT</b> .....	19
<b>TABLE 5: RS-232 PORT SETTINGS</b> .....	19
<b>TABLE 6: RS-232 MONITORING COMMANDS</b> .....	20
<b>TABLE 7: RS-232 CONTROL COMMANDS</b> .....	21
<b>TABLE 8: RS-485 INTERFACE – PIN ASSIGNMENT</b> .....	24
<b>TABLE 9: RS-485 PORT SETTINGS</b> .....	24
<b>TABLE 10: COMMAND MESSAGE FORMAT</b> .....	26
<b>TABLE 11: RESPONSE MESSAGE FORMAT</b> .....	26
<b>TABLE 12: LIST OF COMMANDS</b> .....	27
<b>TABLE 13: REQUEST STATUS – MESSAGE FORMAT</b> .....	28
<b>TABLE 14: REQUEST STATUS – PARAMETER DESCRIPTION</b> .....	28
<b>TABLE 15: SET MUTE/UNMUTE – MESSAGE FORMAT</b> .....	29
<b>TABLE 16: SET MUTE/UNMUTE – PARAMETER DESCRIPTION</b> .....	29
<b>TABLE 17: SET FREQUENCY – MESSAGE FORMAT</b> .....	30
<b>TABLE 18: SET FREQUENCY – PARAMETER DESCRIPTION</b> .....	30
<b>TABLE 19: SET GAIN – MESSAGE FORMAT</b> .....	31
<b>TABLE 20: SET GAIN – PARAMETER DESCRIPTION</b> .....	31
<b>TABLE 21: READ IDENTIFICATION – MESSAGE FORMAT</b> .....	32
<b>TABLE 22: READ IDENTIFICATION – PARAMETER DESCRIPTION</b> .....	32
<b>TABLE 23: READ SERIAL NUMBER – MESSAGE FORMAT</b> .....	33
<b>TABLE 24: READ SERIAL NUMBER – PARAMETER DESCRIPTION</b> .....	33
<b>TABLE 25: READ FREQUENCY RANGE – MESSAGE FORMAT</b> .....	34
<b>TABLE 26: READ FREQUENCY RANGE – PARAMETER DESCRIPTION</b> .....	34
<b>TABLE 27: READ GAIN – MESSAGE FORMAT</b> .....	35
<b>TABLE 28: READ GAIN – PARAMETER DESCRIPTION</b> .....	35
<b>TABLE 29: READ GAIN RANGE – MESSAGE FORMAT</b> .....	36
<b>TABLE 30: READ GAIN RANGE – PARAMETER DESCRIPTION</b> .....	36
<b>TABLE 31: READ FREQUENCY – MESSAGE FORMAT</b> .....	37
<b>TABLE 32: READ FREQUENCY – PARAMETER DESCRIPTION</b> .....	37
<b>TABLE 33: READ TEMPERATURE – MESSAGE FORMAT</b> .....	38
<b>TABLE 34: READ TEMPERATURE – PARAMETER DESCRIPTION</b> .....	38
<b>TABLE 35: STATUS MESSAGE – MESSAGE FORMAT</b> .....	39
<b>TABLE 36: STATUS MESSAGE – PARAMETER DESCRIPTION</b> .....	40
<b>TABLE 37: IDENTIFICATION MESSAGE – MESSAGE FORMAT</b> .....	41
<b>TABLE 38: IDENTIFICATION MESSAGE – PARAMETER DESCRIPTION</b> .....	41
<b>TABLE 39: SERIAL NUMBER MESSAGE – MESSAGE FORMAT</b> .....	42
<b>TABLE 40: SERIAL NUMBER MESSAGE – PARAMETER DESCRIPTION</b> .....	42
<b>TABLE 41: FREQUENCY RANGE MESSAGE – MESSAGE FORMAT</b> .....	43

---

<b>TABLE 42:</b> FREQUENCY RANGE MESSAGE – PARAMETER DESCRIPTION .....	43
<b>TABLE 43:</b> GAIN MESSAGE – MESSAGE FORMAT .....	44
<b>TABLE 44:</b> GAIN MESSAGE – PARAMETER DESCRIPTION .....	44
<b>TABLE 45:</b> GAIN RANGE MESSAGE – MESSAGE FORMAT .....	45
<b>TABLE 46:</b> GAIN RANGE MESSAGE – PARAMETER DESCRIPTION .....	45
<b>TABLE 47:</b> FREQUENCY MESSAGE – MESSAGE FORMAT .....	46
<b>TABLE 48:</b> FREQUENCY MESSAGE – PARAMETER DESCRIPTION .....	46
<b>TABLE 49:</b> TEMPERATURE MESSAGE – MESSAGE FORMAT .....	47
<b>TABLE 50:</b> TEMPERATURE MESSAGE – PARAMETER DESCRIPTION .....	47
<b>TABLE 51:</b> PRODUCT SPECIFICATIONS .....	48
<b>TABLE 52:</b> PACKING LIST (SHIPPING KIT P/N 195-705000-201) .....	49

## **1. INTRODUCTION**

The Advantech Wireless ARUN-70L is an indoor 70 MHz to L-Band Up-Converter designed to interface between 70 MHz modems and L-Band transmitters. With the addition of a Block Up-Converter (BUC) and an amplifier, a complete transmitting satellite system can be implemented with minimum effort.

*Advantech Wireless has prepared this manual for use as a guide for the proper installation, operation and maintenance of Advantech Wireless equipment and computer programs. The drawings, specifications and information contained herein are the property of Advantech Wireless. Unauthorized use or disclosure of these drawings, specifications and information is strictly prohibited. They shall not be reproduced, copied or used in whole or in part as the basis for manufacturing or sale of the equipment or software programs without the prior written consent of Advantech Wireless.*



## 2. PRODUCT DESCRIPTION

The 70 MHz to L-Band indoor Up-Converter consists of a single 19" wide, 1 RU shelf assembly that contains an up-converter from 70 MHz to L-Band. The ARUN-70L also contains a power supply, a reference oscillator, and monitoring and control to manage the Up-Converter unit.

The major features of the ARUN-70L are:

- Up-converts 70 MHz  $\pm$  18 MHz to L-Band (950 – 1525 MHz)
- Phase-locked local oscillator to 10 MHz internal/external reference source
- Front Panel display of status and control functions
- Remote Monitoring and Control via serial interface
- Compact rack-mount package

The ARUN-70L is equipped with an internal 10 MHz reference source. The switch allows the operation of the up-converter using either an internal or an external 10 MHz reference signal. The switching operation depends upon the power level of the externally applied signal.


The externally applied 10 MHz reference power level should be between  $-3$  dBm and  $+3$  dBm and a frequency of  $10$  MHz  $\pm$  2 Hz.

When the externally applied 10 MHz reference power level is less than  $-10$  dBm, the 10 MHz reference will automatically switch to the internal reference. When switching to the internal reference occurs, the up-converter will go OUT OF LOCK for a few seconds due to the instability caused by the transition. The internal reference oscillator reaches its nominal stability 15 minutes after switching to the internal reference. When the 10 MHz input power level is greater than  $-10$  dBm, the system switches to the external reference.


A product outline of the ARUN-70L is given in **Figure 1** and **Figure 2**. A block diagram of the Up-Converter is given in **Figure 3**.

**TABLE 1: CONNECTORS**


<b>Connector</b>	<b>Function</b>	<b>Description</b>	<b>Mating Connector</b>
IF	70 MHz INPUT	BNC-Type (F) 50 $\Omega$	BNC-Type (M) 50 $\Omega$
RF	L-Band OUTPUT	N-Type (F) 50 $\Omega$	N-Type (M) 50 $\Omega$
RELAY	Discrete Interface	DB-9 (F)	DB-9 (M)
RS485	RS-485 Serial Interface	DB-9 (F)	DB-9 (M)
RS232	RS-485 Serial Interface	DB-9 (F)	DB-9 (M)
AC	AC Line	IEC 60320-C14	IEC 60320-C13



**Figure 1: Outline Drawing**



**Figure 2:** Front and Back Panels



**Figure 3: Block Diagram**

### 3. MONITORING AND CONTROL BY THE FRONT PANEL

Local monitoring and control can be done using the keypad, LEDs and the fluorescent display located on the front panel.

#### 3.1 KEYPAD AND FLUORESCENT DISPLAY

Keypad is used to navigate through the various menus provided by the fluorescent display. Here are the basic rules to move between menus.


From main menu, the [**↑**] key is used to go to the shelf menus or the [**↓**] key to go to the up-converter menus.

- The [**↑**] and [**↓**] keys are used to move between parameters.
- The [**←**] and [**→**] keys are used to move between modules.
- The [**Enter**] key is used to edit a parameter.
- The [**↑**], [**↓**], [**←**] and [**→**] keys are used to change value of the selected parameter.
- The [**Enter**] key is used to save changes.
- The [**Cancel**] key is used to discard changes.


**Figure 4: Monitor and Control Menu**, **Figure 5: Shelf Menu** and **Figure 6: Help Menu** provide a flow chart of the menus.

#### 3.2 GAIN ADJUSTMENT

The up-converter 70 MHz to L-Band has a conversion gain of 20 dB. This gain may be adjusted in 0.1 dB steps between 0 dB and 20 dB (20 dB range).




**Figure 4: Monitor and Control Menu**



**Figure 5: Shelf Menu**





**Figure 6:** Help Menu

### 3.3 LEDs

Six LEDs on the front panel provide the status of the Up-Converter. **TABLE 2** gives a description of each LED.

<b>TABLE 2: LED INDICATORS</b>		
<b>LED</b>	<b>Color</b>	<b>Description</b>
STATUS NORMAL	green	Indicates that the Up-Converter is supplied with DC power and it is in good functioning condition
STATUS ALARM	red	An alarm condition has been detected in the Up-Converter.
REF OSC INT	yellow	Indicates that the Up-Converter is locked by the internal reference signal
REF OSC EXT	yellow	Indicates that the Up-Converter is locked by the external reference signal
RF OFF	yellow	The Up-Converter is in MUTE state (no output)
RF ON	green	The Up-Converter is in RF ON state

#### 4. MONITORING AND CONTROL BY THE DISCRETE INTERFACE

This interface offers the essential monitoring and control of the Up-Converter by discrete signals. The discrete interface is located on the rear panel (connector labeled “RELAY”).

Pin 2 and pin 4 together with pin 3 (common) are Form-C relay outputs that provide alarm indication for the Up-Converter.

When the unit is in ALARM condition, pin 2 is closed to pin 3 TX ALARM COMMON, and pin 4 is open relative to pin 3. When the unit is in good functioning condition (NO ALARM), pin 2 is open relative to pin 3, and pin 4 is closed to pin 3.

Pins 1 and 5 allow the operator to mute or un-mute the RF of the Up-Converter. When Pin 1 is connected to pin 5 (MUTE COMMON), the up-converter is un-muted. When Pin 1 is not connected to pin 5, the up-converter is muted.

<b>TABLE 3: DISCRETE INTERFACE – PIN ASSIGNMENT</b>	
<b>Pin Number</b>	<b>Description</b>
1	TX Mute (pin 1 should be connected to pin 5 MUTE COMMON in order to enable the unit)
2	TX Alarm NC (when pin 2 is closed to pin 3 TX ALARM COMMON, the unit is in ALARM condition; when pin 2 is open relative to pin 3, the unit is in good functioning condition)
3	TX ALARM COMMON
4	TX Alarm NO (when pin 4 is open relative to pin 3 TX ALARM COMMON, the unit is in ALARM condition; when pin 4 is closed to pin 3, the unit is in good functioning condition)
5	MUTE COMMON
6	RX Alarm NC (not available for this application)
7	RX Alarm Common (not available for this application)
8	RX Alarm NO (not available for this application)
9	RX Mute (not available for this application)

## 5. MONITORING AND CONTROL BY THE RS-232 INTERFACE

The RS-232 serial interface is a terminal mode interface which allows the operator to monitor and control important parameters of the Up-Converter such as PLL lock status, temperature, conversion gain in each up-converter module, and L-Band frequency of the frequency converter.

### 5.1 ELECTRICAL CONNECTION

The RS-232 port of the Up-Converter can be directly connected to a COM port of computer. The RS-232 port uses a DB9 female connector with pin assignment described in EIA232 standard. See **TABLE 4** for pin assignment. To connect the RS-232 port of the Up-Converter to a PC, use a standard RS-232 cable for computer.

<b>TABLE 4: RS-232 INTERFACE – PIN ASSIGNMENT</b>	
<b>Pin Number</b>	<b>Description</b>
1	Not Connected
2	TX
3	RX
4	Not Connected
5	Ground
6 to 9	Not Connected

### 5.2 PORT SETTINGS

For proper operation, use the following settings:

<b>TABLE 5: RS-232 PORT SETTINGS</b>	
<b>Parameter</b>	<b>Setting</b>
Baud Rate	9600
Data Bits	8
Stop Bit	1
Parity	None

### 5.3 COMMAND DESCRIPTION

To monitor and control an Up-Converter via the RS-232 interface, start a terminal emulation program and use the commands listed in **TABLE 6** and **TABLE 7**.

<b>TABLE 6: RS-232 MONITORING COMMANDS</b>			
<b>Command</b>	<b>Command Description</b>	<b>Option</b>	<b>Option Range</b>
<b>status</b>	Display important information on the Up-Converter.	none	N/A
<b>rf</b>	Display the RF output status (ON or OFF) of the up-converter	none	N/A
<b>freq</b>	Display the output frequency in L-Band of the up-converter.	none	N/A
<b>gain</b>	Display conversion gain of the up-converter	none	N/A
<b>baud port</b>	Display baud rate of the selected port	port	rs232, rs485
<b>address</b>	Display the NMS address of the Up-Converter	none	N/A
<b>serial</b>	Display the serial number of the Up-Converter	none	N/A
<b>update interval</b>	Repeatedly display status of Up-Converter at the selected time interval in secs.	interval	off,[1:3600]
<b>reset</b>	Reset the main controller without service interruption	none	N/A
<b>ver</b>	Display software version	none	N/A
<b>help [command]</b>	Display usage information on the selected command. If <i>command</i> is omitted, a brief description of all commands is given.	command	status, update, rf, freq, gain, baud, address, ver or help

**TABLE 7: RS-232 CONTROL COMMANDS**

<b>Command</b>	<b>Command Description</b>	<b>Option</b>	<b>Option Range</b>
<b>rf</b> <i>module onoff</i>	Turn ON or OFF the RF output of the selected module	module	rx, tx, buc
		onoff	on or off
<b>freq</b> <i>module freq</i>	Set the input/output frequency in L-Band of the selected module.	module	rx, tx
		freq	model dependant
<b>gain</b> <i>module gain</i>	Set conversion gain of the selected module	module	rx, tx, buc
		gain	model dependant
<b>baud</b> <i>port speed</i>	Set baud rate of the selected port.	port	rs232, rs485
		speed	1200, 2400, 4800, 9600, 19200, 28800, 38400, 57600
<b>address</b> <i>addr</i>	Set the NMS address of the shelf.	addr	[1:15]
<b>reset</b>	Resets the main control unit without service interruption.	none	N/A


```
Tera Term - VT
File Edit Setup Control Window Help
> help
LIST OF COMMANDS
status      : Display information on System
rf          : Enable/Disable/Display RF
freq       : Set/Display output/input frequency
gain       : Set/Display conversion gain
baud       : Set/Display baud rate of the selected port
address    : Set/Display the NMS address of the System
serial     : Display serial numbers
update     : Display System status at regular time interval
reset      : Reset main controller without service interruption
ver        : Display software version
help       : Display help on commands

For help on a specific command, type "help <command>"
>
```

```
Tera Term - VT
File Edit Setup Control Window Help
For help on a specific command, type "help <command>"
> help freq
DESCRIPTION:
  Set/Display output/input frequency
USAGE:
  freq <module> [<freq_MHz>]
OPTIONS:
  <module> : Module number: [1]
  <freq_MHz> : output(u/c) frequency in MHz [950 to 1525]
              if <freq_MHz> is omitted, display frequency only
>
```

```
Tera Term - VT
File Edit Setup Control Window Help
For help on a specific command, type "help <command>"
> help gain
DESCRIPTION:
  Set/Display conversion gain
USAGE:
  gain <module> <IF/RF> [<gain_dB>]
OPTIONS:
  <module> : Module number: [1]
  <IF/RF> : IF to represent IF-L or L-IF units
           RF to represent L-RF or RF-L units
  <gain_dB> : IF-L gain in dB [0.0 to 20.0]
             if <gain_dB> are omitted, display gain only
>
```

Figure 7: RS232 Help Menus



```
Tera Term - VT
File Edit Setup Control Window Help

System STATUS      (u/c)
Summary Alarm      :No alarm
BUS status         :OK
PLL status         :Locked
RF status          :RF ON
Frequency          :950 MHz
IF-L/L-IF Gain    :20.0 dB
IF-L/L-IF Temperature: 25 °C

Shroud Temperature : 27 °C
Reference          : internal
```

**Figure 8:** RS232 STATUS Command and Response



## 6. MONITORING AND CONTROL BY THE RS-485 INTERFACE

The Advantech Wireless RS-485 interface provides the operator with serial communication between a computer (or a network controller) and a Converter using the RS-485 4-wire standard. It allows the operator to monitor and control important parameters of the system such as alarms, internal temperature and gain. As opposed to the RS-232 interface, the RS-485 serial interface follows a packet-like structure. A detailed description of the protocol is given in [Sections 6.4](#) and [6.5](#).

### 6.1 ELECTRICAL CONNECTION

The RS-485 port of the Converter can be connected to a COM port of a computer using an RS-232/RS-485 4-wire adapter. The RS-485 port uses a DB9 female connector with pin assignment described in [TABLE 8](#).

<b>TABLE 8: RS-485 INTERFACE – PIN ASSIGNMENT</b>	
<b>Pin Number</b>	<b>Description</b>
1,2,7,8	Not Connected
3	RX-
4	TX-
5	Ground
6	TX+
9	RX+

### 6.2 PORT SETTING

For proper operation, use the following settings:

<b>TABLE 9: RS-485 PORT SETTINGS</b>	
<b>Parameter</b>	<b>Setting</b>
Baud Rate	9600
Data Bits	8
Stop Bit	1
Parity	None

### 6.3 PROTOCOL OVERVIEW

The RS-485 interface follows a packet structure. Each packet consists of 7 bytes of information. The packets can be either a command or a response message. The command messages are sent from a personal computer (or from a network controller) to the Converter and the response messages are sent from the Converter to the computer. The computer cannot initiate more than one command every 40 ms.

The Converter will accept a command only if the first byte contains the appropriate address. If the address of the packet does not match the address of the Converter, the command is ignored. The valid address range is from 0x01 to 0x0F. In the response message, the address is shifted left by 4.

The last byte of the packet is a checksum, which is calculated as the sum of byte 1 to 6. If the checksum is incorrect (packet is corrupted), the command is not executed and no response message is sent. If the command number or the command data is invalid, the command is not executed, and no response message is sent. Unused bytes are set to 0xAA.

The following tables show the general structure of the command message and the response message.

<b>TABLE 10: COMMAND MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0x0				Address			
Byte 2	Command Number							
Byte 3	Command Data							
Byte 4								
Byte 5								
Byte 6								
Byte 7	Checksum							

<b>TABLE 11: RESPONSE MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	Address				0x0			
Byte 2	Response Data							
Byte 3								
Byte 4								
Byte 5								
Byte 6	Checksum							
Byte 7								

## 6.4 COMMAND MESSAGES

The following table provides a list of the supported commands. All other command numbers are reserved.

<b>TABLE 12: LIST OF COMMANDS</b>				
<b>Command</b>	<b>Command Number</b>	<b>Command Format</b>	<b>Expected Response</b>	<b>Response Format</b>
Request Status	0x01 or 0x2A	See <b>TABLE 13</b>	Status Message	See <b>TABLE 35</b>
Set Mute/Unmute	0x02	See <b>TABLE 15</b>	None	N/A
Set Frequency	0x04	See <b>TABLE 17</b>	None	N/A
Set Gain	0x05	See <b>TABLE 19</b>	None	N/A
Read Identification	0x07	See <b>TABLE 21</b>	Identification Message	See <b>TABLE 37</b>
Read Serial Number	0x08	See <b>TABLE 23</b>	Serial Number Message	See <b>TABLE 39</b>
Read Frequency Range	0x09	See <b>TABLE 25</b>	Frequency Range Message	See <b>TABLE 41</b>
Read Gain	0x0A	See <b>TABLE 27</b>	Gain Message	See <b>TABLE 43</b>
Read Gain Range	0x0D	See <b>TABLE 29</b>	Gain Range Message	See <b>TABLE 45</b>
Read Frequency	0x0F	See <b>TABLE 31</b>	Frequency Message	See <b>TABLE 47</b>
Read Temperature	0x12	See <b>TABLE 33</b>	Temperature Message	See <b>TABLE 49</b>

**NOTE:** To store the frequency, gain, address, and mute/unmute control, the redundant system uses a programmable EEPROM with the endurance limited to 100,000 write/erase cycles. Going beyond this limit may affect the operation of the system. Make sure the "Set" commands (0x02, 0x04, 0x05) are used only when needed.

### 6.4.1 REQUEST STATUS (0x01 OR 0x2A)

The request status command is used to retrieve the status of the Converter.

<b>TABLE 13: REQUEST STATUS – MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0x0				Address			
Byte 2	0x01							
Byte 3	0xAA							
Byte 4	0xAA							
Byte 5	0xAA							
Byte 6	0xAA							
Byte 7	Checksum							

<b>TABLE 14: REQUEST STATUS – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

**6.4.2 SET MUTE/UN-MUTE (0x02)**

This command is used to mute or un-mute the Converter

<b>TABLE 15: SET MUTE/UNMUTE – MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0x0				Address			
Byte 2	0x02							
Byte 3	RF Output Ctrl							
Byte 4	0xAA							
Byte 5	0xAA							
Byte 6	0xAA							
Byte 7	Checksum							

<b>TABLE 16: SET MUTE/UNMUTE – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
RF Output Ctrl	Mute or Unmute the RF Output	0x5A: Mute TX 0xA5: Unmute TX 0x0F: Mute RX 0xF0: Unmute RX
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

### 6.4.3 SET FREQUENCY (0x04)

This command is used to set the L-Band frequency of the Converter.

TABLE 17: SET FREQUENCY – MESSAGE FORMAT								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0x0				Address			
Byte 2	0x04							
Byte 3	Direction							
Byte 4	Frequency, integer part MSB							
Byte 5	Frequency, integer part LSB							
Byte 6	Frequency, decimal part							
Byte 7	Checksum							

TABLE 18: SET FREQUENCY – PARAMETER DESCRIPTION		
Parameter	Description	Value
Address	Address of the Converter	0x1 to 0xF
Direction	RF path direction	0x5A: TX 0xA5: RX
Frequency, integer part	Integer part of the L-Band frequency in MHz	Unsigned integer 0x0001 to 0xFFFF
Frequency, decimal part	Decimal part of the L-Band frequency (in MHz) divided by 0.125	0x00 to 0x07
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

#### 6.4.4 SET GAIN (0x05)

This command is used to set the conversion gain of the Converter.

TABLE 19: SET GAIN – MESSAGE FORMAT								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0x0				Address			
Byte 2	0x05							
Byte 3	Module							
Byte 4	Gain, MSB							
Byte 5	Gain, LSB							
Byte 6	0xAA							
Byte 7	Checksum							

TABLE 20: SET GAIN – PARAMETER DESCRIPTION		
Parameter	Description	Value
Address	Address of the Converter	0x1 to 0xF
Module	Converter Module	0x01: IF-L Up-Converter 0x02: L-IF Down-Converter 0x03: L-RF Up-Converter 0x04: RF-L Down-Converter
Gain	Conversion Gain in 0.1 step	Signed integer 0x0000 to 0xFFFF
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF



### 6.4.5 READ IDENTIFICATION (0x07)

This command is used to request the unit type and software version of the Converter.

<b>TABLE 21: READ IDENTIFICATION – MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0x0				Address			
Byte 2	0x07							
Byte 3	0xAA							
Byte 4	0xAA							
Byte 5	0xAA							
Byte 6	0xAA							
Byte 7	Checksum							

<b>TABLE 22: READ IDENTIFICATION – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

### 6.4.6 READ SERIAL NUMBER (0x08)

This command is used to request the serial number of the Converter.

<b>TABLE 23: READ SERIAL NUMBER – MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0x0				Address			
Byte 2	0x08							
Byte 3	0xAA							
Byte 4	0xAA							
Byte 5	0xAA							
Byte 6	0xAA							
Byte 7	Checksum							

<b>TABLE 24: READ SERIAL NUMBER – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

### 6.4.7 READ FREQUENCY RANGE (0x09)

This command is used to request the L-Band frequency range of the Converter.

<b>TABLE 25: READ FREQUENCY RANGE – MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0x0				Address			
Byte 2	0x09							
Byte 3	Direction							
Byte 4	0xAA							
Byte 5	0xAA							
Byte 6	0xAA							
Byte 7	Checksum							

<b>TABLE 26: READ FREQUENCY RANGE – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
Direction	RF path direction	0x5A: TX 0xA5: RX
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

### 6.4.8 READ GAIN (0x0A)

This command is used to request the conversion gain of the Converter.

<b>TABLE 27: READ GAIN – MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0x0				Address			
Byte 2	0x0A							
Byte 3	Module							
Byte 4	0xAA							
Byte 5	0xAA							
Byte 6	0xAA							
Byte 7	Checksum							

<b>TABLE 28: READ GAIN – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
Module	Converter Module	0x01: IF-L Up-Converter 0x02: L-IF Down-Converter 0x03: L-RF Up-Converter 0x04: RF-L Down-Converter
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

### 6.4.9 READ GAIN RANGE (0x0D)

This command is used to request the gain range of the Converter.

TABLE 29: READ GAIN RANGE – MESSAGE FORMAT								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0x0				Address			
Byte 2	0x0D							
Byte 3	Module							
Byte 4	0xAA							
Byte 5	0xAA							
Byte 6	0xAA							
Byte 7	Checksum							

TABLE 30: READ GAIN RANGE – PARAMETER DESCRIPTION		
Parameter	Description	Value
Address	Address of the Converter	0x1 to 0xF
Module	Converter Module	0x01: IF-L Up-Converter 0x02: L-IF Down-Converter 0x03: L-RF Up-Converter 0x04: RF-L Down-Converter
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

**6.4.10 READ FREQUENCY (0x0F)**

This command is used to request the L-Band frequency of the Converter.

<b>TABLE 31: READ FREQUENCY – MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0x0				Address			
Byte 2	0x0F							
Byte 3	Direction							
Byte 4	0xAA							
Byte 5	0xAA							
Byte 6	0xAA							
Byte 7	Checksum							

<b>TABLE 32: READ FREQUENCY – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
Direction	RF path direction	0x5A: TX 0xA5: RX
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

**6.4.11 READ TEMPERATURE (0x12)**

This command is used to request the hot spot temperature of the Converter.

<b>TABLE 33: READ TEMPERATURE – MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	0x0				Address			
Byte 2	0x12							
Byte 3	0xAA							
Byte 4	0xAA							
Byte 5	0xAA							
Byte 6	0xAA							
Byte 7	Checksum							

<b>TABLE 34: READ TEMPERATURE – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

## 6.5 RESPONSE MESSAGES

### 6.5.1 STATUS MESSAGE

The Status Message is sent after reception of the “Request Status” command (0x01 or 0x2A).

TABLE 35: STATUS MESSAGE – MESSAGE FORMAT								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	Address				0x0			
Byte 2	Reserved							
Byte 3	Reserved							
Byte 4	0x1	0x1	DCCOM	0x1	0x1	UCCOM	0x1	0x1
Byte 5	Power Class					CKSM	TXPLL	TXST
Byte 6	0x0				SAL	UCMD	RXPLL	RXST
Byte 7	Checksum							



<b>TABLE 36: STATUS MESSAGE – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
UCCOM (not applicable)	Internal Communication with Converter	0: Communication OK 1: No communication
DCCOM	Internal Communication with Converter	0: Communication OK 1: No communication
Power Class	Rated Power in dBm starting from 30dBm. For rated power less than 30 dBm, Power Class is 0.	0x00 to 0x1F
CKSM	Checksum Error in Command	0: No error 1: Error in checksum
TXPLL	TX PLL Alarm	0: PLL Locked 1: PLL out-of-lock
TXST	TX RF Output Status	0: RF OFF (muted) 1: RF ON (unmuted)
SAL	Summary Alarm	0: No alarm 1: Alarm
UCMD	Unknown Command	0: No error 1: Unknown Command
RXPLL	RX PLL Alarm	0: PLL Locked 1: PLL out-of-lock
RXST	RX RF Output Status	0: RF OFF (muted) 1: RF ON (unmuted)
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

## 6.5.2 IDENTIFICATION MESSAGE

The Identification Message is sent after reception of a “Read Identification” command (0x07).

TABLE 37: IDENTIFICATION MESSAGE – MESSAGE FORMAT								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	Address				0x0			
Byte 2	0x0				Reserved	Reserved	DC	UC
Byte 3	0x0				Reserved	Reserved	Reserved	SPECTR
Byte 4	Unit Type							
Byte 5	0xA				0x0	Reserved	Reserved	Reserved
Byte 6	Software Version							
Byte 7	Checksum							

TABLE 38: IDENTIFICATION MESSAGE – PARAMETER DESCRIPTION		
Parameter	Description	Value
Address	Address of the Converter	0x1 to 0xF
DC	Unit is a Down-Converter	0: No 1: Yes
UC	Unit is an Up-Converter	0: No 1: Yes
SPECTR	RX spectrum inversion	0: RX spectrum not inverted 1: RX spectrum inverted
Unit Type	Type of Frequency Conversion	0x00: N/A 0x01: 70 MHz to L-Band 0x02: 70 MHz to C-Band 0x03: 70 MHz to Ku-Band 0x04: 140 MHz to L-Band 0x05: 140 MHz to C-Band 0x06: 140 MHz to Ku-Band 0x07: L-Band to C-Band 0x08: L-Band to Ku-Band
Software Version	Software Version of the Converter	0x01 to 0xFF
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

### 6.5.3 SERIAL NUMBER MESSAGE

The Serial Number Message is sent after reception of the “Read Serial Number” command (0x08).

<b>TABLE 39: SERIAL NUMBER MESSAGE – MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	Address				0x0			
Byte 2	Character 1							
Byte 3	Character 2							
Byte 4	Character 3							
Byte 5	Character 4							
Byte 6	Character 5							
Byte 7	Checksum							

<b>TABLE 40: SERIAL NUMBER MESSAGE – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
Character 1 to 5	ASCII Code of Character 1 to 5	0x00 to 0x7F
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

#### 6.5.4 FREQUENCY RANGE MESSAGE

The Frequency Range Message is sent after reception of the “Read Frequency Range” command (0x09).

<b>TABLE 41: FREQUENCY RANGE MESSAGE – MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	Address				0x0			
Byte 2	Lowest Frequency, MSB							
Byte 3	Lowest Frequency, LSB							
Byte 4	Direction							
Byte 5	Highest Frequency, MSB							
Byte 6	Highest Frequency, LSB							
Byte 7	Checksum							

<b>TABLE 42: FREQUENCY RANGE MESSAGE – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
Lowest Frequency	Lowest L-Band Frequency in MHz	Unsigned integer 0x0000 to 0xFFFF
Highest Frequency	Highest L-Band Frequency in MHz	Unsigned integer 0x0000 to 0xFFFF
Direction	RF Path direction	0x5A: TX 0xA5: RX
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

### 6.5.5 GAIN MESSAGE

The Gain Message is sent after reception of the “Read Gain” command (0x0A).

<b>TABLE 43: GAIN MESSAGE – MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	Address				0x0			
Byte 2	Gain, MSB							
Byte 3	Gain, LSB							
Byte 4	0xAA							
Byte 5	0xAA							
Byte 6	0xAA							
Byte 7	Checksum							

<b>TABLE 44: GAIN MESSAGE – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
Gain	Conversion Gain in 0.1 dB step	Signed integer 0x0000 to 0xFFFF
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

### 6.5.6 GAIN RANGE MESSAGE

The Gain Range Message is sent after reception of the “Read Gain Range” command (0x0D).

<b>TABLE 45: GAIN RANGE MESSAGE – MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	Address				0x0			
Byte 2	Lowest Gain, MSB							
Byte 3	Lowest Gain, LSB							
Byte 4	Module							
Byte 5	Highest Gain, MSB							
Byte 6	Highest Gain, LSB							
Byte 7	Checksum							

<b>TABLE 46: GAIN RANGE MESSAGE – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
Lowest Gain	Lowest conversion gain in 0.1 dB step	Signed integer 0x0000 to 0xFFFF
Highest Gain	Highest conversion gain in 0.1 dB step	Signed integer 0x0000 to 0xFFFF
Module	Converter Module	0x01: IF-L Up-Converter 0x02: L-IF Down-Converter 0x03: L-RF Up-Converter 0x04: RF-L Down-Converter
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

### 6.5.7 FREQUENCY MESSAGE

The Frequency Message is sent after reception of the “Read Frequency” command (0x0F).

<b>TABLE 47: FREQUENCY MESSAGE – MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	Address				0x0			
Byte 2	Frequency, integer part MSB							
Byte 3	Frequency, integer part LSB							
Byte 4	Direction							
Byte 5	Frequency, decimal part							
Byte 6	0xAA							
Byte 7	Checksum							

<b>TABLE 48: FREQUENCY MESSAGE – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
Frequency, integer part	Integer part of the L-Band frequency in MHz	Unsigned integer 0x0001 to 0xFFFF
Frequency, decimal part	Decimal part of the L-Band frequency (in MHz) divided by 0.125	0x00 to 0x07
Direction	RF Path direction	0x5A: TX 0xA5: RX
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF

### 6.5.8 TEMPERATURE MESSAGE

The Temperature Message is sent after reception of the “Read Temperature” command (0x12).

<b>TABLE 49: TEMPERATURE MESSAGE – MESSAGE FORMAT</b>								
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1	Address				0x0			
Byte 2	Temperature, MSB							
Byte 3	Temperature, LSB							
Byte 4	0xAA							
Byte 5	0xAA							
Byte 6	0xAA							
Byte 7	Checksum							

<b>TABLE 50: TEMPERATURE MESSAGE – PARAMETER DESCRIPTION</b>		
<b>Parameter</b>	<b>Description</b>	<b>Value</b>
Address	Address of the Converter	0x1 to 0xF
Temperature	Temperature in 0.1° Celsius	Signed integer 0x0000 to 0xFFFF
Checksum	Sum of byte 1 to byte 6	0x00 to 0xFF



## 7. PRODUCT SPECIFICATIONS

The following specifications characterize the performance of the Advantech Wireless Up-Converter, P/N 170-705000-201.

<b>TABLE 51: PRODUCT SPECIFICATIONS</b>	
Input Frequency	70 ± 18 MHz
Output Frequency	950 – 1525 MHz (1 MHz step) no spectrum inversion
Frequency Adjustment Step	1 MHz
Conversion Gain	20 ± 1 dB @ +23 °C and 1350 MHz
Gain Adjustment Range	20 dB (from 0.0 dB to +20.0 dB)
Gain Adjustment Step	0.1 dB
Frequency Response Flatness	2.0 dB p-p, max (over 36 MHz)
Input Return Loss	16 dB, min
Output Return Loss	16 dB, min
Input Power Level	-40 to -10 dBm
Output Power (P <sub>1dB</sub> )	+5 dBm, min
In band Spurious	-55 dBm @ P <sub>out</sub> = 0 dBm, G = 20 dB
Third Order Intermodulation (two equal tones 5 MHz apart)	- 40 dBc, max @ SCL 13 dB back-off (P <sub>out total</sub> = -5 dBm)
Phase Noise @ offset	100 Hz -63 dBc/Hz 1 kHz -73 dBc/Hz 10 kHz -83 dBc/Hz 100 kHz -93 dBc/Hz
Internal Reference Frequency	10 MHz
External 10 MHz Reference (optional)	10 MHz sine wave, -3 dBm to +3 dBm
IF Input Port	BNC (f) 50 Ω
RF Output Port	N-type (f) 50 Ω
RS-232 Interface	D-sub 9 (f)
RS-485 Interface	D-sub 9 (f)
Relay Interface	D-sub 9 (f)
Power Connector	IEC 60320 10 amp
Power Consumption	40 Watt typical
Panel Height	1 RU of 19" rack

**8. PACKING LIST**

<b>TABLE 52: PACKING LIST (SHIPPING KIT P/N 195-705000-201)</b>			
<b>Item</b>	<b>Quantity</b>	<b>Description</b>	<b>Part #</b>
<b>1.</b>	1	Installation and Operating Manual	PM 170-705000-201 Rev. 2n
<b>2.</b>	1	Up-Converter 70 MHz $\pm$ 18 MHz to L-Band model ARUN-70L	170-705000-201
<b>3.</b>	3	Connector D-Sub 9 Sold Cup Plug	631-871380-003
<b>4.</b>	3	Connector D-Sub 9 Backshell Plastic with Thumb Screws	631-925380-001
<b>5.</b>	1	3-Cond IEC 320 M/F Power Cord 10A 250V, 2.5-3 m long	670-315008-001
<b>6.</b>	1	Slide Non-pivoting 124 C-300-SRC Solid Bearing (optional, delivered if ordered separately)	815-300124-002

## **9. APPENDIX A: SAFETY AND EMC COMPLIANCE**

Advantech Wireless products are compliant with following standards:

**SAFETY:** IEC 60950-1 second edition 2005

**EMC:** EN301489-1 2004 (EMC for radio equipment and services, common technical requirements):

- EN 55022: 1998 / A1: 2000 - Class A
- EN61000-4-4 Transient/burst 0.5kV Signal Lines, 1 kV Power Lines
- EN61000-4-2 Electrostatic discharge 4kV CD, 8 kV AD
- EN61000-4-5 Surge 1kV, 0.5 kV
- EN61000-4-11 AC port dips 70%, 40%, 0%
- EN 61000-4-3 Radiated Immunity 80-1000 MHz @ 3 V/m

### **SUPPLEMENTARY INFORMATION:**

The products herewith comply with the requirements of the Low Voltage Directive 73/23/EEC and of the EMC Directive 89/336/EEC and may carry the CE-marking accordingly.